


TRANSCRIBE DRY ERASE WALLCOVERING



EASE OF INSTALLATION

Installs just like a Type II commercial wall covering. Normally railroaded to avoid vertical seams on the writing surface.

EASY TO MAINTAIN

Dry erase markings are removed with a soft cloth or eraser. Expo cleaner can be used for any resistant markings. Surface should be throughly cleaned periodically for best performance and appearance. DO NOT USE any abrasive cleaning tools or harsh solvents. Writing surface could be permanently damaged if instructions are not followed.

TEN YEAR WARRANTY

Transcribe Dry Erase Wall Covering is guaranteed for 10 years from installation date. With proper use and maintenance, our product will perform for a minimum of 10 years. See detailed cleaning and maintenance instructions for proper care.

Visit odysseywallcoverings.com for Specifications, Installation Instructions and more.

TRANSCRIBE DRY ERASE WALLCOVERING

SPECIFICATIONS



Total Weight	Minimum Type II
Width	Projection 59"/60" Magnetic 47"/48" Writing Only 59"/60" Magnetic Projection Capable 47"/48"
Flame Resistance	Class A/I
Tensile and Tear	Meets all Type II standards
Solvent Resistance	Class 5 (ASTM D4752 using Expo Blue Cleaner)

FEATURES

- Dry erase marks clean easily
- Large writing area
- Simple installation like standard commercial wallcovering
- Class A fire rated
- Resistant to common cleaners
- 10-year limited warranty
- Cost effective
- Practical alternative to whiteboards
- Ideal for converting existing chalkboards
- Available in Magnetic, Projection, Magnetic Projection Capable and Writing Only

CARE & MAINTENANCE

Prior to initial use, clean dry erase surface thoroughly with Expo cleaner. Follow with clean, warm water applied with a soft towel. Periodically clean the entire writing surface to extend the life and look of this product. Expo Bold Colour/Original Ink markers work best on Transcribe.

WARNING! Do not use any type of abrasive cleaners or sharp-edged tools on the dry erase surface.

INSTALLATION

Installs like a standard Type II commercial wallcovering. Smoothing tools must be wrapped in a soft cloth or towel to avoid damage to the dry erase surface. Request detailed installation instructions.

Visit odysseywallcoverings.com for Specifications, Installation Instructions and more.





ACCESSORIES



EASE OF INSTALLATION

Transcribe Wallcovering installs just like Type II commercial wallcovering. Normally railroaded to avoid vertical seams in the writing surface. SNAP! is a clear coating that is rolled over any colour flat latex paint.

EASY TO MAINTAIN

Dry erase markings are removed with a soft cloth or eraser. Expo cleaner can be used for any resistant markings. Surface should be thoroughly cleaned periodically for best performance and appearance. DO NOT USE any abrasive cleaning tools or harsh solvents. Writing surface could be permanently damaged if instructions are not followed.

TEN YEAR WARRANTY

Our Dry Erase products are guaranteed for 10 years from installation date. With proper use and maintenance our product will perform for a minimum of ten years. See detailed cleaning and maintenance instructions for proper care.



Care and Maintenance

Before Writing on Dry Erase Surface

Before initial use of the writing surface the material must be cleaned with Expo Cleaner and a soft cloth, and then towel dried. Follow with clean water and a soft cloth. Use another clean towel to dry.

Markers

We recommend the use of Expo Bold Colour/Original Ink markers.

Daily Cleaning

Micro-fiber erasers or cloths are recommended to remove the dry erase markings. Change or clean the eraser/cloth often to avoid leaving excessive marker residue on the surface. For cleaning marker residue build-up, use Expo brand Whiteboard Cleaner and a soft cloth. Projection Capable items have a matte/low-glare dry erase surface that requires more frequent cleaning than Writing Only/gloss material. No markings will be permanent, but it may be necessary to use Expo Cleaner to bring these Projection Capable products back to "like new" condition.

Do not use soapy water to clean the surface, as it will leave behind a film that severely interferes with erasing. This is true of any other cleaning agent that leaves a filmy residue behind.

Long Term Care

Clean the entire surface on a regular basis to insure the ultimate performance and appearance of the product over the long term.

Do not use abrasive cleaners/cleaning tools, erasers with hard plastic edges/housing or pointed writing instruments on the dry erase surface.