

The Manufacturing Process of SanFoot Recon Series

SanFoot Recon wood veneers are manufactured from natural hardwood logs such as Plantation (FSC) Poplar. With this technically enhanced manufacturing process we can achieve the desired look and consistency of color and pattern.

1. Rotary cut veneer




Poplar logs are rotary sliced.

2. Dyeing of veneer

The sliced veneers are sub-merged in a 100% water-based dyed bath to achieve the desired color.



3. Gluing of the Veneer and Pressing



Multiple colors of veneer and glue lines are used to create the pattern. The stack of veneers are placed in a specific mold pattern to create the desired block.

4. Slicing the block. Manufacturing into SanFoot


First the block is sliced into veneer faces. The veneer faces are pressed onto SanFoot's unique Class A backer and prefinished.




5. Primary Benefits of SanFoot

- Natural Wood - Class A Fire-Rated
- Consistent grain and color
- Large matching runs - Prefinished
- FSC available on most patterns


SanFoot Recon Face Patterns



QUARTERED PATTERN
(STRAIGHT GRAIN)



FLAT CUT PATTERN
(CATHEDRAL WITH
THREE CROWNS)



PLANK PATTERN
(SPLIT HEARTS
QUARTERS)