

BRAQUE WALL PANEL INSTALLATION INSTRUCTIONS

PRECAUTIONS



Always wear work gloves, safety glasses and mask when cutting this product.

By installing this product, you confirm that you have consulted the installation instructions and acknowledge your approval of the product and its warranty.

TOOLS

- 100% polyurethane construction glue (3 tubes per 100 ft²)
- Caulking gun
- Miter saw
- Table saw
- Level
- Measuring tape
- Cutter
- Pneumatic finish nailer
- #23 gauge finish nails
- Stepladder

WALL PANELS MUST BE GLUED AND NAILED FOR A SUCCESSFUL INSTALLATION AND TO PREVENT FUTURE WARPING.

CEILING APPLICATIONS:

Special glues must be specified by the onsite engineer or architect with the use of #18 gauge nails and installed by a licensed contractor or carpenter. Structural weight limitations need to be considered.

Ceiling applications are not covered by the warranty.


Do not install over material other than drywall or plywood.

MAKE SURE YOUR KNIVES AND SAWBLADES ARE IN TOP CONDITION.

FIRST, check that the wall is level from floor to ceiling and edge to edge. If not, adjust accordingly.

STEP 1: If you are using mouldings, mark spacing around the perimeter of the installation area.

STEP 2: Cut the excess wood to be straight with the backing.




STEP 3:


A Apply a line of 100% polyurethane glue (1/2" from the edge) and an X inside the rectangle on the back of the wall panel.




B Apply glue on the exposed backing, top and right edges.



STEP 4: Position the first panel at the lower left section of the wall. If using mouldings, position the panel in area designated in Step 1.




STEP 5: Nail the panel in place with #23 gauge finish nails on the exposed backing and at an angle between wood slats of the bottom rows. NEVER NAIL DIRECTLY TO THE FACE OF THE WOOD SLATS.



x = #23

STEP 6: Installation of subsequent panels.

- For the first row only: Cut the excess of the wood at the bottom of the wall panel.
- Repeat step 3.
- Align panel B against panel A.
- Repeat step 5.



STEP 7: End row / Cut any excess of the wall panel flush with the edge of the wall.

STEP 8: Start a new row / Use the remaining piece from the previous row making sure the pattern aligns or use a new piece. Repeat Step 3 and 5.

STEP 9: Last row / Cut the panels of the last row lengthwise to fit the available space. If required, allow enough space for the mouldings

STEP 10: Insert the mouldings in previously designated area if required.

NOTE: A detached wood slat can be reglued using the same glue as for the installation.

Manufacturer guarantees the conformity of its products when they are installed according to installation instructions and maintained in an environment where ambient humidity ranges between 35% and 55%. Failure to comply with installation instructions shall void the application of the Warranty.

PRIOR TO INSTALLATION, PLACE CARTONS IN ORIGINAL PACKAGING FLAT ON THE FLOOR OF PLANNED ROOM.

